

Programming EVADE – Printable Instructions

Clearing the Main Headset

When programming a repaired or replaced EVADE, the MAIN headset needs to be **cleared** before a Remote can be paired. Follow the steps below to clear the MAIN. All Remote headsets should be OFF before starting this process.

1. With all system equipment off, install battery in MAIN headset and press power button to turn on (LED flashes green).
2. Quickly press volume down button 3 times, then press and HOLD volume up button. LED will flash green/red. The MAIN is now in **program mode**.
3. Press and hold the volume down button for 5 seconds until red LED flashes quickly. This clears the MAIN headset (Skip to step 3 below).

Programming EVADE Remote Headsets

1. Press power button on MAIN to turn on headset, (LED flashes green).
2. Quickly press volume down 3 times, then press and HOLD volume up button. LED will flash green/red. The main is now in **program mode**.
3. Power on the Remote EVADE headset(s) to be programmed, (LED flashes green).
4. Quickly press volume down 3 times, then press and HOLD volume up button. LED will flash green/red, then quickly flash green. The LED will then turn solid RED. The headset is now programmed.
5. Once all remote headsets have been programmed, press the power switch to turn off all headsets and complete the programming process.