

DV Balancer® and Balancer® ENG – A new type of shoulder support



DV Balancer® classic compact for transport



DV Balancer® Memory Clip stores the setting.



DV Balancer® for direct "docking" on all Chrosziel Light-weight supports of the 401- 4xx series or Camera Adaptor 3100.

The DV Balancer® comfortably places camcorders with built-in viewfinders in front of the eye leaving the hands free for camera control.

Shoulder support for cameras up to 4 kg, adjusts vertically and horizontally allowing the user to view the viewfinder eyepiece. The weight of the camera will be absorbed by the shoulder pad and the chest rest leaving the hands free to control the camera. The camera attachment allows a direct "docking" on all Chrosziel light-weight supports of the 401-4xx series, additional to the 1/4" fastening screw and rubber cushion. For transporting, the chest rest and shoulder unit are separated. The so-called "Memory Clip" stores the individual adjustment, for immediate re-installation after unpacking.

New!



DV Balancer® ENG for angled ENG viewfinders and **DSLR-** cameras with video function.

Components	Article no.
DV Balancer® * classic, as shown	3000
DV Balancer® * classic, with short shoulder rod	3020
DV Balancer® * classic, with Belly Rest	3025
DV Balancer® ENG*, straight versin with Belly Rest; for cameras with ENG viewfinder, e. g: Sony PMW-EX3	3030
ShoulderPad proVideo	3035
HandleBar proVideo	403-10
Accessories	
DV Balancer® Camera Adaptor	3100
DV Balancer Belly Rest with curved pad instead ball breast rest	S3316018

* For use on 15mm DV Lightweight supports

DV Balancer® Design and functionality are protected by DE 202007005393 and international registration.
Balancer® is a registered trademark of Chrosziel GmbH.

DV Balancer® – The accessories, HandleBar proVideo and ShoulderPad proVideo



The **Lightweight supports in the 401-4xx series** are tripod adapters, support for the MatteBoxes and focus control devices and, at the same time, connection to the DV Balancer®.



The **HandleBar proVideo** (Art.-No. 403-10) fits to all LightWeight Support of Chrosziel series 401-4xx but also to all other supports with 15mm rods. For cameras without a built-in shoulder pad, for example all **VDSLR** cameras, the **ShoulderPad proVideo** (Art.-No. 3035) is added. It slides into the base of the support series 401-400 in the same way as the DV Balancer®. The fast changing between shoulder and tripod is maintained.



Use the **Balancer® Camera adapter** Art. No. 3100 for cameras without supports



Battery Holder (Art. No. 3200) with a universal adapter plate with holes and threads for Anton/Bauer Gold Mount, IDX V-Plate and PAG Lok battery systems. In the illustration with PAG Lok.



The **Tripod Clamp** (Art. No. 3220) is also available for use of the **DV Balancer®** battery holders on tripods with parallel-rod legs and rod diameters between 16 - 36 mm.



HandleBar proVideo
(Art.-No. 403-10)

ShoulderPad proVideo
(Art.-No. 3035)

In addition to the Chest Rest, a **Belly Rest** S3316018 is available, Standard with Balancer®ENG. Art. No. 3025 and 3030.

DV Balancer® Design and functionality are protected by DE 202007005393 and international registration. Balancer® is a registered trademark of Chrosziel GmbH.