


5. REPAIR PARTS LIST

5-1-8. EVF SECTION

ns : not supplied



Ref. No.	Part No.	Description
351	X-3953-896-1	CABINET ASSY, VF (REAR)
352	3-087-515-01	EYE CUP
353	X-3953-895-1	CABINET (LOWER) ASSY,VF(FRONT)
354	X-3950-565-1	HINGE ASSY, VF
355	3-080-204-51	SCREW, TAPPING, P2
356	1-678-060-21	FP-193 FLEXIBLE BOARD
357	A-7078-958-A	LB-100D BOARD, COMPLETE
358	3-072-211-01	ILLUMINATOR

Ref. No.	Part No.	Description
359	3-072-210-01	SHEET, PRISM
360	3-087-530-01	SHEET, LIGHT INTERCEPTION
361	X-3953-897-1	HOLDER ASSY, LCD
362	3-087-528-01	CABINET (UPPER), VF (FRONT)
363	3-072-214-01	GUIDE (20), LAMP
364	3-087-529-01	CUSHION, LCD
LCD903	8-753-036-73	LCX033APA-1