



- 2. Deck Control
- 3. R-Y Out
- 4. Y Out
- 5. B-Y Out
- 6. Ref In
- 7. R-Y In
- 8. Y In
- 9. B-Y In
- 10. AES/EBU Out
- 11. AES/EBU In
- 12. Audio Out Left
- 13. Audio Out Right
- 14. Audio In Left
- 15. Audio In Right



DeckLink HD Extreme and Professional Breakout Cable

- 3. R-Y Out
- 4. Y Out
- 5. B-Y Out
- 7. R-Y In
- 8. Y In
- 9. B-Y In
- 10. AES/EBU Out
- 12. Audio Out Left
- 13. Audio Out Right
- 14. Audio In Left
- 15. Audio In Right



DeckLink HD Extreme and Consumer Breakout Cable