

Mount Plate for Panasonic AW-UE150 PTZ Camera (PGX.PTZ150.0)

The Universal Mounting System for the Panasonic AW-UE150 PTZ is a modular mounting system that covers a wide range of typical mounting requirements for the Panasonic AW-UE150 PTZ camera.

The basis of this modular mounting system is the **Mount Plate for AW-UE150** (PGX.PTZ150.0), which is attached directly to the Panasonic AW-UE150 PTZ. This provides the camera a solid mounting base to which a wide variety of mounting adapters can be easily attached without having to remove the camera from the base plate when changing the mounting method.

The **Basic Plate** (PGX.PTZ150.1) extends the Mount Plate for AW-UE150 with stable and durable 1/4" and 3/8" threads. It is the universal adapter plate when the Panasonic AW-UE150 PTZ needs to be securely mounted on changing tripod heads or other 1/4" and 3/8" assemblies.

With the **75mm Half Ball Adapter** (PGX.PTZ150.2), the Mount Plate for AW-UE150 becomes suitable for use with 75mm tripod bowls. This allows the Panasonic AW-UE150 to be mounted on compatible tripods without using a fluid head. By removing the Half Ball Adapter, the Mount Plate for AW-UE150 can also be mounted directly flat on compatible tripods or bowls. This even allows mounting on half ball bowls up to 150mm.

The **Basic Click Plate** (PGX.PTZ150.3) makes the Mount Plate for AW-UE150 compatible with VCT-14 VCT-14 Quick Release tripod plate.

The **Wall Adapter** (PGX.PTZ150.4) for the Mount Plate for AW-UE150 enables the Panasonic PTZ camera to be easily mounted on vertical walls. The Mount Plate for AW-UE150 can be mounted to the Wall Adapter Plate at various angles to the wall and can be mounted upright or in a hanging position.

The **Truss Adapter** (PGX.PTZ150.5) with integrated safety rope eyelet extends the Mount Plate for AW-UE150 by the option of mounting on standard 5/8" pin. For example, the PTZ camera can be mounted upright on a tripod, or hanging from a truss using a G-/Super Clamp. A black 40cm safety rope is included.



Mount Plate for AW-UE150 PTZ Camera (PGX.PTZ150.0)


Wall Adapter (PGX.PTZ150.4)

Half Ball Adapter (PGX.PTZ150.2)

Basic Plate (PGX.PTZ150.1)

Basic Click Plate (PGX.PTZ150.3)

Truss Adapter (PGX.PTZ150.5)




Mount Plate for AW-UE150 PTZ Camera (PGX.PTZ150.0)

1/4" Camera mounting screws included.




Basic Plate (PGX.PTZ150.1)

Universal Basic Plate with 1/4" and 3/8" threads.
M5 mounting screws included.




Half Ball Adapter (PGX.PTZ150.2)

75mm Half Ball Adapter to mount AW-UE150 PTZ to Tripod without a Fluid Head or to mount the Universal Mounting Plate flat on a Tripod Bowl.




Basic Click Plate (PGX.PTZ150.3)

The Basic Click Plate makes the Mounting Plate compatible with VCT-14 plates.
M5 mounting screws included.



Wall Adapter (PGX.PTZ150.4)

The wall adapter allows you to mount the USP mounted PTZ camera also on vertical walls. Thanks to intelligent drill holes, the USP can be mounted at various angles to the wall. M5 mounting screws included.



Truss Adapter (PGX.PTZ150.5)

With the Truss Adapter it is easy to hang up the Mounting Plate for AW-UE150 mounted AW-UE150 PTZ to any compatible 5/8" pin. The Truss Adapter has a Safety Eyelet for a Safety Rope and a M3 thread to connect the camera's own Safety Mounting Screw. 40cm Safety Rope is included.

