



No.	Part No.	SP Description
51	X-2318-450-1	s PAD SUB ASSY
52	3-080-203-31	s SREW(M2),LOCK ACE, P2
53	3-876-782-02	s SHAFT PAD
54	3-876-783-01	s COVER,PAD CENTER
55	3-878-246-01	s COVER, PAD STOPPER
56	3-878-248-01	s SPRING PAD
57	3-364-941-11	s SCREW (+B) (2.6X5), NYLOK
58	3-654-058-12	s SPACER (3X2)
59	3-080-203-31	s SREW(M2),LOCK ACE,P2
60	3-701-444-21	s WASHER 6
61	3-878-278-01	s SIDEPAD L
62	3-878-281-05	s BOTTOM COVER, SIDEPAD L
	7-685-534-19	s SCREW +BTP 2.6X8 TYPE2 N-S