



## Multi-sockets Square Cine Battery

**PB-S146A/S 146Wh**



LCD info



V-mount



Gold mount



D-tap x2



USB x1

## PB-S146A/S 146Wh

- ◆ Square shape design for Cine-cameras
- ◆ 146Wh, 10.1Ah Capacity
- ◆ Constant 200W, 16A high load
- ◆ 2× D-tap output sockets
- ◆ 1× USB 5V/2A power output sockets
- ◆ LCD display accurate remaining run time
- ◆ Display power info in both SONY & RED

**PB-S146A: Gold mount**

**PB-S146S: V-mount**

| Model                |            | PB-S146S      | PB-S146A      |
|----------------------|------------|---------------|---------------|
| Battery plate        |            | V-mount       | Gold mount    |
| Nominal voltage      |            | 14.4V         | 14.4V         |
| Capacity             |            | 146Wh, 10.1Ah | 146Wh, 10.1Ah |
| Max output           | Electrodes | 200W, 16A     | 200W, 16A     |
|                      | D-TAP      | 120W, 10A     | 120W, 10A     |
|                      | USB        | 10W, 5V/2A    | 10W, 5V/2A    |
|                      | In total   | 200W          | 200W          |
| Dimension            |            | 121×95×59mm   | 121×95×59mm   |
| Net weight           |            | 0.878kg       | 0.873kg       |
| Max charging current |            | 5A            | 5A            |

**Power info display** – Remaining power percentage, remaining working time, low power warning, and battery cycle times.



Display power percentage when the battery is free or during charging.



Display remaining running time when the battery is powering on camera or any devices. Press power check button can switch to power percentage display.



When remaining running time is less than 15 minutes, the LCD will flash to remind changing battery.



Long press power check button for 5 seconds, it will display battery cycle times.



Display warning info when the battery detected over discharging, over charging current / voltage, over load, short circuit, etc. Refer the warning code to User Manual to take steps.

