



No.	Part No.	SP Description
601	A-1772-494-A	s MOUNTED CIRCUIT BOARD, PD-119 (RP)
602	A-1752-742-B	s DOOR (L) ASSY, SWITCH
603	A-1752-743-C	s DOOR (R) ASSY, SWITCH
604	A-1752-744-A	s DOOR ASSY, MENU
605	A-1752-745-B	s PANEL SUB ASSY, INSIDE
606	3-603-680-02	s STAINLESS SCREW +B3X12
607	3-629-768-52	s ORNAMENTAL PLATE(3), SW, CAMERA
608	3-680-219-03	s KNOB, VR
609	3-703-357-03	s PIN, PARALLEL (DIA. 1.6X6)
610	3-719-381-02	s SCREW (M2X4)
611	3-724-758-02	s RUBBER (PUSH), DROP PROTECTION
612	3-797-073-01	s RES, SW PUSE
613	3-855-938-01	s SCREW
614	3-879-092-01	s SHEET, SW PANEL
615	4-169-001-01	s VR KNOB(2)
616	4-169-004-01	s LABEL, FILTER INDICATION
617	4-169-006-01	s PAD, INSIDE
618	4-169-018-01	s VR KNOB(S)
619	4-169-021-01	s WINDOW, LCD

7-685-146-11 s SCREW +P 3X8 TYPE2 NON-SLIT